



LOADING TIPS FOR AN OPTIMAL RIDE




MOVE LOAD TO CENTER

Move load/weight toward the center of the bike.



MOVE LOAD DOWN

Move load/weight down toward the ground. Use pannier bags.



CENTER/BALANCE LOAD

Center load/weight. Distribute equal weight on each side.



HOLD HANDLEBAR FIRMLY

Keep hands firmly on handlebar while riding with load.

MAX 130LB
60KG

MAX 260LB
120KG

MAX 45LB
20KG

BIKE 65LB/30KG

**MAX GROSS WEIGHT
440LB/200KG**

BENNO BOOST E (MY 2020 AND LATER)

DO NOT EXCEED MAX GROSS WEIGHT OF 440 LB / 200 KG (RIDER + CARGO + BIKE) BE AWARE, WHEN ADDED TOGETHER, THE INDIVIDUAL LOAD RATINGS SHOWN FOR THE RIDER AND CARGO PLUS THE ACTUAL WEIGHT OF THE BIKE WILL EXCEED MAX GROSS WEIGHT. THEREFORE, WHILE YOU MAY MAXIMIZE SELECTED INDIVIDUAL LOAD RATINGS, THE SUM OF ALL LOADS CANNOT EXCEED THE MAX GROSS WEIGHT (RIDER + CARGO + BIKE \leq 440 LB / 200 KG).

WARNING: RIDE WITHIN YOUR LIMITS. ADDING LOAD INCREASES RIDING DIFFICULTY. SECURE LOAD FIRMLY. ENSURE THAT NO PARTS OF THE LOAD, BODY OR CLOTHING COME NEAR MOVING PARTS ON THE BICYCLE, SUCH AS CHAIN, SPOKES, TIRES OR BRAKES.

HOLD HANDLEBAR FIRMLY WHILE RIDING WITH LOAD. MAINTAIN PROPER TIRE PRESSURE AS INDICATED ON TIRES.