



LOADING TIPS FOR AN OPTIMAL RIDE




MOVE LOAD TO CENTER

Move load/weight toward the center of the bike.



MOVE LOAD DOWN

Move load/weight down toward the ground. Use pannier bags.



CENTER/BALANCE LOAD

Center load/weight. Distribute equal weight on each side.



HOLD HANDLEBAR FIRMLY

Keep hands firmly on handlebar while riding with load.

MAX 85LB 40KG

MAX 260LB 120KG

MAX 35LB 15KG

BIKE 55 LB / 25 KG

MAX GROSS WEIGHT 400 LB / 180 KG

BENNO EJOY/ESCOUT

DO NOT EXCEED MAX GROSS WEIGHT OF 400 LB / 180 KG (RIDER + CARGO + BIKE) BE AWARE, WHEN ADDED TOGETHER, THE INDIVIDUAL LOAD RATINGS SHOWN FOR THE RIDER AND CARGO PLUS THE ACTUAL WEIGHT OF THE BIKE WILL EXCEED MAX GROSS WEIGHT. THEREFORE, WHILE YOU MAY MAXIMIZE SELECTED INDIVIDUAL LOAD RATINGS, THE SUM OF ALL LOADS CANNOT EXCEED THE MAX GROSS WEIGHT (RIDER + CARGO + BIKE \leq 400 LB / 180 KG).

WARNING: RIDE WITHIN YOUR LIMITS. ADDING LOAD INCREASES RIDING DIFFICULTY. SECURE LOAD FIRMLY. ENSURE THAT NO PARTS OF THE LOAD, BODY OR CLOTHING COME NEAR MOVING PARTS ON THE BICYCLE, SUCH AS CHAIN, SPOKES, TIRES OR BRAKES.

HOLD HANDLEBAR FIRMLY WHILE RIDING WITH LOAD. MAINTAIN PROPER TIRE PRESSURE AS INDICATED ON TIRES.